





# VCR Use With A DTA Box



## Recording on your VCR with a DTA box:

With TCC converting to an all “digital” system, all TV’s will need either a set-top receiver, a built-in QAM tuner or a **DTA box**. Connecting a DTA box means a change to the way you record with a standard VCR. In this guide, we will go through the basic steps for connecting and recording with your VCR when you have a DTA box connected to your TV.

## Connecting your VCR:



Connect Cable Line from wall outlet to the “IN” outlet on the DTA box

Connect another Cable Line from the “Out” outlet on the DTA box to the “In” outlet on your VCR

Connect Cable Line from the “Out” outlet on your VCR and connect to the cable outlet on the back of your TV (use same cable, connection you used before)

## 3 Big Keys to Remember:

- \* **Always leave your TV and VCR on Channel 3 (or 4).** (per DTA switch) That is the only channel that the DTA will send the signal to your TV and VCR.
- \* To record on your VCR or program your VCR to record, **set your VCR to Channel 3** and then make sure your **DTA** is turned to the channel you want to record when the program starts.
- \* **Your VCR records whatever channel the DTA is on.** This means you can no longer watch one channel and record another with a VCR.

**A DVR makes recording super easy!** If this new process for recording with a VCR does not work for you, consider getting a DVR receiver from TCC. A DVR comes with HD Cable and you can add it to Digital or Basic Cable. Using a DVR is much faster and easier than a VCR.

